

## **WinCCU 5.28 Service Pack**

Warning!!!!!!

This WinCCU 5.28 product update is intended to be used with WinCCU32 5.20 or newer software. Do not attempt to update an older version (WinCCU 5.18 or older) of WinCCU. The program will copy the setup and associated files to your c:\temp\winccu528 directory (temporary directory). If one doesn't exist the program will create this directory for you. The program will automatically run setup.exe to install the update.

### **Changes**

1. Correct inability to access a sequel database with WinCCU5.28 after the database had been accessed using WinCCU6X.
2. Correct problem with analysis edits where editor analysis events didn't match analysis in the characteristics record. This caused a recalc problem.
3. Correct problem with analysis edits using a date range.
4. Add utility to align analysis events with analysis in the characteristics record.